

# **Ecosmarte Planet Friendly, Inc.**

## **Operating a Spa System Important Points**

1. You IONIZE only at new fillup 4 to 10 hours til copper ppm reaches .5ppm
2. The system is switched to High Oxidize and operates 4 to 8 hours per day. Two three hour cycles is most common
3. The spa will not ionize at start up until ph is adjusted downward to 6.8
4. At fresh fill it is typically three ph down adjusts WEEK ONE, two ph adjustments down WEEK TWO and once per week for week three thru 20 weeks. The acid required to move the PH in week three is one fourth the acid needed in week one

Take notes, the acid demand will be identical the second time you fill your spa.